

**PV import** A/S

# Elektronisk Reservedelskatalog

Version 1.0 - marts 2004

Elektriske Kogeplader

Cooking Theatres

Integreret Opvask

Ovne

Micro



Køl & Køl/Frys

Gaskogeplader

Em-Fang

**Diverse Servicemeddelser**



Tlf. 8726 2300 - Fax 8726 2301



Service Tlf. 8726 2305




*Ovne*


**AS 1 SS**  
**AS 2 SS**  
**AS 3 SS**  
**AS 8 SS**  
**AS 8 SKAL-A**  
**AS 13 SKX-A**  
**AS 14 SKM-A**  
**AS 15 SK-AL**  
**AS 19 SKX-A**  
**B 100X SK-B**  
**B 155 SS**  
**B 187 HVID**  
**B 187 SORT**  
**B 187 SS**  
**B 187 SKBL-B**  
**B 187 SKW-B**  
**B 187 SKX-B**  
**B 209 SKX-A**  
**B 240 SKX-A**  
**B 260.1 SKX-A**  
**B 270 SKM-A**  
**B 275 SKM-A**  
**B 484 SKX-A**  
**B 495 DK SS**  
**B 495 SKX-A**  
**B 497 DK SS**  
**B 550 SK GBL-A**  
**B 897**  
**B 897 SK X-C**  
**B 900 SKX-B**  
**BT 401 SORT**  
**BT 401 SS**  
**BT 585 SS**  
**Megachef 2 SK.M**  
**TG1 TANGO**

**P620 SK.A**  
**P640 SK.A**  
**P 650 SK.X PYRO.**  
**P 660 SK.X TOUCH**  
**P 900 SK.X.A**




*Micro-ovne*

**BTM 17 SK-X**  
**BTM 17.3 SS**  
**BTM 23.1 SK-X**  
**BTM 23.2 M**  
**BTM 24 DK SS**  
**BTM 25 SS**  
**PCM 355**




*Cooking Theatres*

**BRC 2 IV**  
**BRC 2 BDY**  
**BRC 2 GBL**  
**BRC 3 IV**  
**BRC 3 GBL**  
**BT 2360**  
**BT 2365 TC**  
**BT 2380**  
**BT 2385 TC**  
**BT 2760 TC**  
**BT 2850 TC**  
**TS 1**  
**TS 2 TC**  
**ALABAMA**  
**INDIANA**  
**LOUISIANA**  
**MISSISSIPPI**  
**TENNESSEE**  
**PT 2800 SS**  
**PT 2815 SK.X**  
**PT 2810 SS**



*Em-Fang*


**AS 29SK.GL**  
**AS 32 SK.GL**  
**BT 09**  
**BT 09.2 SK.X**  
**BT 09.5 SK.X**  
**BT 26 SK.X**  
**BT 29 SK.X**  
**BT 83 SK.GL**  
**BT 90**  
**BT 91 X**  
**BT 100 X**  
**BT 120 X**  
**ISL 96SK.GL**  
**P 14 SK.X**  
**P 15 SK.X**  
**P 20 SK.X**  
**P 30 SK.X**  
**P 31 SK.X**  
**P 35 SK.X**  
**PI 2 SK.X**  
**PI 3 SK.X**  
**XX 70 SS**  
**XX 90 SS + FARVER**  
**XX 120 SS**




**Køl - Køl/Frys**

**BF 207 SLM**  
**BF 207 BLM**  
**BF 337 SS**  
**BF 373 SS**  
**BF 585 SL**  
**BFE 320 SS**  
**BFE 350 SS**  
**BLE 360 SS**  
**BR 15 A**  
**BR 200 A**  
**BR 200.3A**  
**BR 22/8 A**  
**BR 23.8A**  
**BV 14 A**  
**BZE 290 SS**  
**FI 9230/E**  
**FI 9314/E**  
**Reflex**  
**RETRO 1 creme**  
**RETRO 1 silver**  
**RETRO 2 creme**  
**RETRO 2 silver**  
**TITAN 1**  
**TITAN 2**

**BF 346**




**Kaffemaskiner**

**BEC 2**



**Ismaskiner**

**EASYISE 1 SL**



**Vinkølere**

**BWE 40**  
**BFW440**





**Varmeskuffe**

**PD 3 SS**



**Friture**

**PF 1 SS DOMINO**




*El-kogeplader*

**AS 6**  
**AS 27 SS**  
**B13 DK**  
**B13 SK**  
**B 15 DK**  
**B 16 DK**  
**B 23 SK-BEL Induktion/High**  
**B 24 Induktion**  
**B 24 SK-BEL Induktion**  
**BBQ SKX**  
**BF 13 SK**  
**BF 14.1M-BEL**  
**BF 15 SK**  
**BF 15 SK-BEL**  
**BF 15 SKX**  
**BF 16 SK-BEL**  
**BF 16.1 SK-BEL**  
**BF 25.1 SK.X**  
**BH 12**  
**BH 65**  
**BTC 2 SKX**  
**BTC 2.1SKX**  
**BW 14 DK**  
**BVC 2 DK/SK**  
**IP 60225**  
**IP 80225**  
**PBQ SS**  
**PVC 2 SKX**  
  
**BHC 606BE**



*Gas-kogeplader*

**AS 5**  
**AS 26 SS**  
**B 17.5 TC X**  
**B 68 TC**  
**B 68 TC GBL**  
**BG 2 TC**  
**BT 16.7**  
**BT 62 TC**  
**BT 66 TC X**  
**BWK 1 TC**  
**P 62 SK.X**  
**P 68 SKX**  
**P 75 SK.X**  
**P 76 SKX**  
**P 90 SKX**  
**PG 2 SK.X**  
**PWK 1 SK.X**

 *Opvaskemaskiner*

**BDI 680**  
**BHD 6**  
**BDW 8**  
**BDW 14**  
**BDW 15**  
**BDW 17**  
**SUPREAM 1 SS**  
**SUPREAM 1 W**  
**SUPREMA 2 SS**

